

UV Resin Arabesque Pendant

Level: Intermediate/ Advanced



Completed piece



Design pattern

<Materials>

Art Clay Silver 650/1200 Clay Type	10g
Art Clay Silver 650/1200 Syringe Type	5g
Art Clay Silver 650/1200 Paste Type	some
Resin color Black	some
UV resin (clear)	some
Resin color Aqua	some
Bail back	1 pc

<Step by Step Guide>



- 1) Roll out the clay 1.5mm thick, place the pattern sheet, then cut out the clay with a steel scraper on the edges, and dry completely.



- 2) Flatten the sides of the piece with sandpaper (#320).



- 3) Smooth the surface with a red sponge sanding pad.



- 4) Draw the lines based on the pattern with a pencil.



- 5) Extrude syringe line in double layers with a green nozzle on the guideline, and dry completely.



- 6) Fill in any gaps between the syringe line and the base with some Paste Type.



- 7) Attach a bail back to the top of the base with some Paste Type, dry completely, and fire.



- 8) Polish the entire piece with a stainless steel brush, and make a mirror finish on the sides with a burnisher.



- 9) Attach transparent tape around the piece. Mix proportion UV color Black 3 to Aqua 1, and mix it with UV resin. Paint it approx. 1mm thick, and cure the piece in UV Light Box. TIP: If you mix UV resin with too dark a color it will not cure.



10) Pour some UV resin so as to cover the syringe lines, and cure in the box.



11) After curing completely, remove the tape and file the UV surface flat until the syringe line appears.



12) Put some water on the piece, and polish with sandpaper (#600, 1200, and 2000 in order). Put some polish compound for plastic & metal to silver cloth, polish and finish.